



# SNOW FENCE WE KNOW FENCE


## FEATURES & BENEFITS

Quest® Better Barriers™ Snow Fence controls drifting and blowing snow.

- stronger than competitive non-oriented fences
- engineered to control drifting and blowing snow and sand
- place 30 feet from desired drift-free area
- high tear resistance
- reusable
- easy to use

## RETAIL ROLLS

SF 4850 X	4' x 50' (1.2 m x 15.2 m)	roll (orange)	0 57180 00390 1
SF 48100 X	4' x 100' (1.2 m x 30.4 m)	roll (orange)	0 57180 00391 8
SF 4850 B	4' x 50' (1.2 m x 15.2 m)	roll (black)	0 57180 00460 1



Made in Canada

## EASY TO INSTALL INSTRUCTIONS

1. Determine the direction of the prevailing winds in your area and align the fence perpendicular to this direction for optimum drift control. Install the fence a minimum of 30' from the desired drift-free area.
2. T-Posts should be inserted a minimum of 1.5' in the ground and a maximum of 8' (2.4m) apart.
3. Vertical strands of fence must be sandwiched between the flat side of the T-Post and 1" x 2" wood slat.
4. Secure the wooden slat, fence and the T-Post together using our Better Barriers™ Re-Usable Locking Ties spaced at 1' intervals (see illustration).
5. Start the next roll by overlapping a minimum of 6" of fence at the last T-Post and then sandwich the 2 layers of fence as described in step 3.
6. Fence should be tensioned by hand only. DO NOT USE MECHANICAL TENSIONERS.
7. For the most efficient drift control, allow a 6" gap between the ground and fence bottom. This gap will allow a much longer and higher drift, greatly prolonging the effectiveness of the fence.

### ACCESSORIES REQUIRED

Suggested accessories required for installation of 50 feet of our Better Barriers™ Snow Fence.

- 7 steel T-Posts (minimum 6 feet high)
- 7 wooden slats 1" x 2" x 4'
- 35 Quest® Better Barriers™ Re-usable Locking Ties 10" long

